UAB SAFETY SHORT

Attention Researchers who use Stericycle:

UAB received a notice that Stericycle's Autoclave Waste Processing Team has detected dangerous levels of formaldehyde in their autoclaves while processing UAB waste. Since this is dangerous to inhale, it has caused them to stop work until air quality is restored. They are seeing yellow containers inside of red bags and cardboard boxes. Yellow containers require incineration and should not be autoclaved. Stericycle utilizes yellow QR code labels to specify waste to be incinerated, compared to white stickers for normal medical waste to be autoclaved.

Pathological waste- Human or animal body parts, organs, tissues, and surgical specimen: You MUST decant formaldehyde, formalin, or other preservatives, as required per hazardous waste regulations. Shipping pathological waste with preservatives not only endangers Stericycle workers but also puts UAB at risk of noncompliance with hazardous shipping regulations.

It is ultimately the researcher's responsibility to ensure their laboratory waste is properly identified, packaged, and segregated.

Please use the Stericycle chart below to determine what is acceptable regulated medical waste and how it should be segregated. Contact medwaste@uab.edu for ordering Stericycle labels, requesting transport containers, and scheduling pickups.





FACILITIES | ENVIRONMENTAL DIVISION | HEALTH & SAFETY