



NMR Data Pre-processing


UAB Metabolomics Training Course

June 14-18, 2015


Wimal Pathmasiri, Rodney Snyder
NIH Eastern Regional Comprehensive Metabolomics Resource Core
(RTI RCMRC)

NIH Common Fund Metabolomics Cores



NIH Metabolomics Centers Ramp Up | November 4, 2013 Issue - Vol. 91 Issue 44 | Chemical & Engineering News. by Jyllian Kemsley




NIH Eastern Regional Comprehensive Metabolomics Resource Core at RTI




LC-MS, MS/MS and ION-MOBILITY



Multivariate and Statistical Analysis



Predictive Modeling





Pathway Mapping Metabolites-Proteins-Genes




T A R G E T E D

B R O A D S P E C T R U M



NMR Metabolomics Workflow



Data Pre-processing

- After NMR data acquisition, the result is a set of spectra for all samples.
- For each spectrum, quality of the spectra should be assessed.
 - Line shape
 - Phase
 - Baseline
- Spectra should be referenced
 - Compounds commonly used: DSS, TSP, Formate
- Variations of pH, ionic strength of samples has effects on chemical shift
 - Peak alignment
 - Bucket integration
- Remove unwanted regions

Quality Control Steps


- Quality of metabolomics analysis depends on data quality

- Typical problems
 - Water peak (suppression issues)
 - Baseline (not set at zero and not a flat line)
 - Alignment of peaks (chemical shift, due to pH variation)
 - Variation in concentration (eg. Urine)


- High quality of data is needed for best results

Water Suppression Effects and Other Artifacts

- If water is not correctly suppressed or removed there will be effects on normalization
- Need to remove other artifacts
- Remove drug or drug metabolites



Poor water suppression





Good water suppression

Same Serum sample

NMR Pre-processing

Before

After



Phase
Baseline to be
corrected

Reference,
Line shape


pH Dependence of Chemical Shift

Chemical shift variability

- pH
- ionic strength
- metal concentration

Methods to overcome this problem


- Use a buffer when preparing samples
- Binning (Bucketing)
 - Fixed binning
 - Intelligent binning
 - Optimized binning
- Available data alignment tools
 - Recursive Segment-wise Peak Alignment (RSPA)
 - Icoshift
 - speaq



Example

icoshift


One of the Citrate peaks



Peak Alignment

Example


speaq



Vu, T. N. et al., *BMC Bioinformatics* 2011, **12**:405

NMR Binning


- A form of quantification that consists of segmenting a spectrum into small areas (bins/buckets) and attaining an integral value for that segment
- Binning attempts to minimize effects from variations in peak positions caused by pH, ionic strength, and other factors.
- Two main types of binning
 - Fixed binning
 - Flexible binning




NMR Binning

Peak shift can cause the same peak across multiple samples to fall into different bins

- The entire NMR spectrum is split into evenly spaced integral regions with a spectral window of typically 0.04 ppm.
- The major drawback of fixed binning is the non-flexibility of the boundaries.
- If a peak crosses the border between two bins it can significantly influence your data analysis





Fixed Binning



NMR Binning


Signals for citrate are split into multiple bins

Fixed Binning





Signals for citrate are properly captured

Smart Binning



NMR Binning





- Integrate bins (0.04 ppm bin size)
- Normalize integral of each bin to the total integral of each spectrum
- Merge metadata
- Result is a spreadsheet ready for further multivariate data analysis and other statistical analysis

Sample ID	Disease Group	[0.40 .. 0.46]	[0.46 .. 0.52]	[0.52 .. 0.54]	[0.54 .. 0.57]	[0.57 .. 0.60]	[0.60 .. 0.66]	[0.66 .. 0.68]	[0.68 .. 0.71]	[0.71 .. 0.75]
C0559	Cases	7.60E-05	0.00E+00	7.32E-02	8.48E-02	3.20E-02	1.84E+00	1.31E-01	3.60E-01	3.67E-01
C0629	Cases	0.00E+00	1.78E-02	0.00E+00	2.18E-02	0.00E+00	1.08E+01	0.00E+00	0.00E+00	3.02E-02
C0640	Cases	3.44E-04	0.00E+00	1.83E-03	1.86E-04	0.00E+00	4.51E+00	0.00E+00	0.00E+00	0.00E+00
C0835	Cases	6.41E-04	0.00E+00	6.44E-03	0.00E+00	3.96E-03	3.28E+00	0.00E+00	5.12E-03	1.75E-02
D0613	Cases	6.63E-03	0.00E+00	0.00E+00	1.06E-02	0.00E+00	5.79E+00	0.00E+00	6.36E-02	3.02E-01
D0762	Cases	0.00E+00	0.00E+00	1.79E-02	1.98E-02	0.00E+00	9.37E+00	0.00E+00	0.00E+00	1.74E-02
D1113	Cases	3.14E-03	2.42E-03	8.02E-02	1.04E-01	5.32E-03	3.74E+00	0.00E+00	2.02E-02	1.84E-01
D1158	Cases	0.00E+00	3.71E-03	2.35E-02	4.83E-02	0.00E+00	5.02E+00	0.00E+00	1.91E-02	0.00E+00
D2090	Cases	0.00E+00	0.00E+00	2.45E-03	9.98E-04	0.00E+00	5.76E+00	0.00E+00	1.24E-02	1.04E-02
E0004	Cases	1.72E-03	0.00E+00	6.85E-02	3.05E-02	0.00E+00	1.47E+00	6.90E-02	3.61E-01	4.08E-01
E0195	Cases	0.00E+00	1.69E-03	5.57E-02	6.29E-02	0.00E+00	2.77E+00	1.34E-01	2.04E-01	4.56E-01
E0225	Cases	1.25E-03	0.00E+00	4.40E-03	1.69E-02	0.00E+00	9.17E+00	0.00E+00	1.08E-02	2.30E-02
E0309	Cases	4.11E-03	0.00E+00	2.23E-02	7.54E-03	3.08E-03	3.54E+00	0.00E+00	3.28E-02	9.09E-01
E0487	Cases	1.72E-03	0.00E+00	0.00E+00	1.00E-02	0.00E+00	4.00E+00	0.00E+00	1.36E-02	0.00E+00
F0036	Cases	1.66E-02	0.00E+00	0.00E+00	2.06E-02	0.00E+00	1.22E+01	1.04E-02	0.00E+00	5.97E-01
F0108	Cases	0.00E+00	2.31E-03	6.30E-03	1.11E-02	0.00E+00	7.17E+00	0.00E+00	1.65E-02	2.21E-01
A0233	Control	0.00E+00	1.86E-02	0.00E+00	1.82E-02	0.00E+00	1.61E+01	0.00E+00	2.91E-03	0.00E+00
A0490	Control	0.00E+00	0.00E+00	2.99E-03	3.60E-02	0.00E+00	2.97E+00	0.00E+00	4.00E-02	5.46E-01
A2003	Control	0.00E+00	0.00E+00	3.45E-02	2.20E-02	0.00E+00	1.80E+00	0.00E+00	0.00E+00	0.00E+00
C0586	Control	0.00E+00	1.69E-02	0.00E+00	6.64E-03	0.00E+00	1.92E+01	0.00E+00	6.51E-02	0.00E+00
C2177	Control	0.00E+00	0.00E+00	3.02E-02	3.59E-02	0.00E+00	2.35E+00	0.00E+00	3.19E-02	1.49E-01
D0177	Control	9.21E-03	0.00E+00	1.69E-02	1.47E-02	0.00E+00	2.43E+00	0.00E+00	4.46E-02	0.00E+00
D0729	Control	0.00E+00	1.88E-03	5.58E-02	7.87E-02	2.92E-02	3.16E+00	6.59E-02	2.80E-01	4.30E-01
D0909	Control	0.00E+00	1.08E-03	0.00E+00	5.69E-03	0.00E+00	2.49E+00	0.00E+00	1.01E-02	1.87E-01
D0945	Control	0.00E+00	4.79E-04	7.00E-03	0.00E+00	4.19E-03	3.99E+00	0.00E+00	1.11E-03	3.96E-02
D1174	Control	0.00E+00	9.33E-04	0.00E+00	3.43E-03	1.30E-02	7.21E+00	6.53E-03	0.00E+00	1.66E-02
D2054	Control	1.55E-03	0.00E+00	0.00E+00	1.22E-02	0.00E+00	2.07E+00	0.00E+00	1.28E-02	3.90E-01
D2062	Control	2.39E-05	0.00E+00	6.04E-02	2.99E-02	0.00E+00	4.94E+00	0.00E+00	9.95E-03	0.00E+00
D2079	Control	2.73E-02	0.00E+00	1.81E-03	1.17E-02	0.00E+00	3.38E+01	7.87E-02	0.00E+00	5.91E+00

Data Normalization, Transformation, and Scaling

- Normalization reduces the sample to sample variability due to differences in sample concentrations—particularly important when the matrix is urine
 - Normalization to total intensity is the most common method
 - For each sample, divide the individual bin integral by the total integrated intensity
 - Other Methods
 - Normalize to a peak that is always present in the same concentration, for example normalizing to creatinine
 - Probabilistic quotient normalization
 - Quantile and cubic spline normalization

Centering, Scaling, and Transformations

I Centering

$$\tilde{x}_{ij} = x_{ij} - \bar{x}_i$$

II Autoscaling

$$\tilde{x}_{ij} = \frac{x_{ij} - \bar{x}_i}{s_i}$$

Range scaling

$$\tilde{x}_{ij} = \frac{x_{ij} - \bar{x}_i}{(x_{i_{\max}} - x_{i_{\min}})}$$

Pareto scaling

$$\tilde{x}_{ij} = \frac{x_{ij} - \bar{x}_i}{\sqrt{s_i}}$$

Vast scaling

$$\tilde{x}_{ij} = \frac{(x_{ij} - \bar{x}_i)}{s_i} \cdot \frac{\bar{x}_i}{s_i}$$

Level scaling

$$\tilde{x}_{ij} = \frac{x_{ij} - \bar{x}_i}{\bar{x}_i}$$

III Log transformation

$$\tilde{x}_{ij} = {}^{10}\log(x_{ij})$$

$$\hat{x}_{ij} = \tilde{x}_{ij} - \bar{\tilde{x}}_i$$

Power transformation

$$\tilde{x}_{ij} = \sqrt{(x_{ij})}$$


$$\hat{x}_{ij} = \tilde{x}_{ij} - \bar{\tilde{x}}_i$$

Analysis results vary depending on the scaling/ transformation methods used.


Van den Berg et al 1006, BMC Genomics, 7, 142

Data Transformation

- Before transformation
 - skew distribution



- After log-transformation
 - More close to normal distribution






- Unit variance (autoscaling) divides the bin intensity by the standard deviation
 - May increase your baseline noise
 - Dimensionless value after scaling

- Pareto scaling divides the bin intensity by the square root of the standard deviation
 - Not dimensionless after scaling

- For NMR data, centering with pareto scaling is commonly used

Multivariate Data Analysis and Other Statistical Analyses

- Mean centered and scaled data
- Non-supervised analysis
 - Principal component analysis (PCA)
- Supervised analysis
 - PLS-DA and OPLS-DA
- Loadings plots and VIP Plots to identify discriminatory bins
- p-Value, fold change



ACKNOWLEDGEMENTS

Director RTI RCMRC

Susan Sumner, PhD

Program Coordinator

Jason Burgess, PhD

NIH Scientific Officer

David Balshaw, PhD, NIH/NIEHS

Internship Program

Stella Lam, BS

Feasibility Studies

Susan Sumner, PhD

Susan McRitchie, MS

Executive Committee

Website

Roger Austin, MS

Biochemistry and

Molecular Biology

Timothy Fennell, PhD

Ninell Mortensen, PhD

Delisha Stewart, PhD

Biorepository

Brian Thomas, PhD

Mike McCleary, BS

Interns

Tammy Cavallo

Aastha Ghimire

Zachery Acuff

LC-MS Metabolomics

Suraj Dhungana, PhD

Brian Thomas, PhD

James Carlson, MS

Alex Kovach, BS

Rodney Snyder, MS

Moses Darko, BS

GC-MS Metabolomics

Wimal Pathmasiri, PhD

Jocelin Deese-Spruill, BS

Keith Levine, PhD

James Harrington, PhD

William Studabaker, PhD

NMR Metabolomics

Wimal Pathmasiri, PhD

Kelly Mercier, PhD

Rodney Snyder, MS

Tammy Cavallo, BS

Kevin Knagge, PhD, DHMRI

Jason Winnike, PhD, DHMRI

**Statistics, Bioinformatics,
and Computing**

Susan McRitchie, MS

Robert Clark, PhD

Andrew Novokhatny, BS

Advisors: Imperial College, UK

Jeremy Nicholson, PhD

Elaine Holmes, PhD

Ian Wilson, PhD