





Nuclear Magnetic Resonance (NMR) Spectroscopy - Detects NMR active nuclei - Robust and highly reproducible - Non-destructive - Quantitative - Used in - Structure elucidation - Small molecules - Macromolecules (DNA, RNA, Proteins) - A number of techniques - 1D, 2D, 3D - Molecular motion and dynamics - Similar method used in Imaging (MRI, fMRI)








			NMR Spectroscopy
Freq	uencies in 11.7T m	agnet	
	Nucleus	Basic Frequency (MHz)	Natural Abundance (%)
	¹ H	500	100
	² H	77	0.015
	³ H	533	0.005
	¹³ C	126	1.11
	35CI	49	75.53
	³⁷ Cl	41	24.47
	¹⁵ N	50	0.37
	¹⁹ F	470	100
	³¹ P	202.5	100
	⁵⁷ Fe	16.25	2.20
/ANCE Beg	inners User Guide 004 (E	Bruker, Germany)	
			nd Examples for Organic Chemistry 2007, ISBN 978-0-471-73096-5




















RTI International

Sample Preparation for metabolomics

- Balance and calibration check
- Prepare samples on ice, Minimize freeze thaw cycles
- Dilution
 - Using D₂O or Buffer (0.2M Phosphate)
- Extraction
 - MeOH or MeOH/ Water
 - MeOH/ CHCl₃/ H₂O (Folch Method)
 - 50% Acetonitrile in Water
 - Dry the sample
 - Reconstitute in D₂O or 0.2M Phosphate Buffer
- Internal standards
 - Chemical shift reference (DSS, also for line shape)
 - pH reference (Imidazole)
- Pooled QC Samples
- Consistency across the whole study is very important



RTI International


Sample Preparation for Metabolomics Analysis


Current sample preparation practices (in brief)


- Biofluids
 - Dilute with D₂O/ buffer/ 0.9% Saline
 - Add internal standard (ISTD, eg. Chenomx) solution or formate (for serum).
 - Centrifuge and transfer an aliquot into NMR tube
- Tissue and Cells
 - Homogenization performed in ice cold 50/50 acetonitrile/water
 - Supernatant dried down (lyophilized)
 - Reconstituted in D₂O and ISTD (eg. Chenomx) solution
- Pooled QC Samples (Sample Unlimited)
 - Mix equal volume of study samples to get pooled QC samples
 - 10% QC samples
- Pooled QC Samples (Sample Limited)
 - Use independent pool of similar samples
 - 10% QC samples
- Daily balance and pipette check

Samples are randomized for preparation and data acquisition









RTI International

Steps in Data Acquisition

- Place the sample in the spinner
 - Use sample gauge
- Tune and match the probe
 - Automatic in new instruments
- Lock and shim the instrument
 - Gradient shimming
- Create and set up NMR parameters
- Acquire data
- Process the NMR spectrum



